

2 PIECE MAGNETIC UNDERWATER LED LIGHTED POOL LIGHTS FOR ABOVE GROUND POOLS

Pool light is specially designed for above ground (vinyl and steel walled) pools. It uses an internal magnet to affix the light to the inside of the pool wall. Easy to install and remove.

Quick Setup Instructions

1 POOL LIGHT

OPEN

Grip firmly and use pressure and turn the top clear cover counter clockwise to open

2

Insert 3 AA batteries (not included)
Do Not Mix Old and New Batteries
Do Not Mix Alkaline, Standard, or Rechargeable Batteries

Take the tap of battery cover to open easily

3

CLOSE

Match the tap of battery cover to fit on the column on bottom

Replace the battery cover over the LEDs. Replace the clear cover, turning clockwise until snug. Be sure the gasket is clean, lubricated with silicone grease and properly sealed.

4 REMOTE CONTROL

Remove the tab to activate the battery

Insert a #2032 button cell battery (comes preinstalled)

5

1. Press button once to turn on (low setting)

2. Press again for the high setting

3. Press a third time to shut off

REMOTE OPERATION

Point the remote directly at the clear cover of the light unit. This is important when the unit is submerged in a swimming pool.

6

STEEL PLATE (INCLUDED)

VINYL WALL

STEEL WALL

This product is for use with above ground pool walls with a maximum thickness of .5mm (0.02in), or rigid steel walls.

7

DON'T

The remote control is not waterproof. Do not submerge.

Ensure that all threads are engaged and cover is fully and evenly sealed on to gasket before submerging. Failure to properly seal unit will cause leaks, which will destroy the light and void the warranty.

- WARNING:**
1. Contains strong magnets. Keep light away from young children, mobile phones, magnetic media such as hard drives and other electronic devices.
 2. Always make sure the product is thoroughly dry before inserting batteries.
- STORAGE:**
1. Where freezing temperatures occur, there is danger of damaging the product. It is recommended to remove, clean, remove the batteries, and store the product in a safe place when the temperature drops below 42° Fahrenheit.
 2. Thoroughly air-dry all pieces prior to storage.
 3. If the product is not going to be used for longer than one month, remove the batteries, clean them and store lights and remote control to prevent discharge and corrosion.